



Revision
09/19/24
9700112

LCE Front Light Bar (84-88 Pickup / 84-89 4Runner)

1. Remove factory carriage bolts from bumper in some case you may need to chase the threads for the new hardware (M10x1.25)



2. Install new supplied hardware from behind the bumper into the light bar.



3. Tighten down approximately 30 ftlbs.

